iHome™

IH-K220CB

wireless multimedia keyboard & optical mouse

user manual

Congratulations on the purchase of your new **wireless multimedia keyboard & optical mouse**. This product comes with a limited lifetime warranty.

Before using your product, please thoroughly read and follow the instructions inside this manual.

If you still need help, see the back page for other support options.

If you want to know more about our products, visit us online at **www.life-works.com**.

system requirements

- Windows® 2000, XP or Windows Vista®
- USB port
- CD-ROM drive

your package should contain



wireless multimedia keyboard



4 AAA batteries



wireless optical mouse



nano USB receiver

user manual
(in your hands right now)

user manual contents

features • 2
your new keyboard • 3
your new mouse • 4
connect hardware • 4
install software • 6
product operating tips • 9
troubleshooting • 10

features

- plug-n-play—no synching needed
- 10 internet and media launch keys
- 4-button optical mouse
- programmable keyboard buttons

IH-K220_UM.indd 2 11/11/2008 1:13:34 PM

your new keyboard



IH-K220_UM.indd 3 11/11/2008 1:13:34 PM

your new mouse



connect hardware

1. Insert 2 AAA batteries into the keyboard battery compartment.



IH-K220_UM.indd 4 11/11/2008 1:13:34 PM

2. Insert 2 AAA batteries into the mouse battery compartment.



3. Connect the nano USB receiver to an available USB port on your computer. The keyboard and mouse automatically connect to the USB receiver.



4. Start using your keyboard and mouse.

To set up the advanced functions of your keyboard, install the supplied software.

IH-K220_UM.indd 5 11/11/2008 1:13:35 PM